



U-COM 16

Quick guide



Product details




CHECK FOR SOFTWARE UPDATES
ON WEBSITE
www.interphone.com



Cellularline S.p.A.
Via Lambrakis 1/A, 42122 Reggio Emilia, Italy
www.cellularline.com

Installation



Using the hook and loop fasteners for main unit







Using the double sided adhesive tapes for main unit



Using the clamp for main unit




Installing the speakers and the microphone




Mesh Intercom Antenna

Pull the mesh intercom antenna inwards slightly to unfold it.




Legenda and basic functions

Press once Press twice Press three times Press and hold for 1 sec Press and hold for 5 sec Press and hold for 10 sec




Power on

Power off




Volume increase

Volume decrease



Charging




Voice commands


| Action | Command |
|---------------------------------|----------------------------------|
| Start Mesh intercom | Hey Interphone, Mesh On |
| Stop Mesh intercom | Hey Interphone, Mesh Off |
| Set Open Mesh mode | Hey Interphone, Open Mesh |
| Set private Mesh mode | Hey Interphone, Group Mesh |
| Group creation for private Mesh | Hey Interphone, Mesh Grouping |
| Action | Command |
| Bluetooth® intercom pairing | Hey Interphone, Pairing Intercom |
| Connect intercom one | Hey Interphone, Intercom one |
| Connect intercom two | Hey Interphone, Intercom two |
| Connect intercom three | Hey Interphone, Intercom three |
| Stop intercom | Hey Interphone, end Intercom |
| Action | Command |
| Phone pairing | Hey Interphone, phone pairing |
| Answer a phone call | Hello |
| Reject a phone call | Ignore |
| Start Google assistant | Hey Google |
| Start Siri | Hey Siri |
| Action | Command |
| Music play via Bluetooth® | Hey Interphone, play music |
| Music stop | Hey Interphone, stop music |
| Start FM radio | Hey Interphone, FM radio on |
| Stop FM Radio | Hey Interphone, FM radio off |
| Track/Station next | Hey Interphone, next |
| Track/Station previous | Hey Interphone, previous |
| Check battery level | Hey Interphone, check battery |
| Increase listening volume | Hey Interphone, volume up |
| Decrease listening volume | Hey Interphone, volume down |

Bluetooth® devices pairing


Main phone pairing (to be done with unit on)



Second phone pairing (to be done with unit on)



Gps SATNAV & TFT pairing (to be done with unit on)




Phone pairing




Phone

Incoming call answer | End call | Reject incoming call



Phone assistant trigger | Speed dial



Music and FM radio

Music play | Music pause | Next track | Previous track



Start/stop music sharing | Start/stop FM radio




Next station | Previous station




Mesh Intercom - OPEN MESH

OPEN MESH mode (default) | Start/stop intercom OPEN MESH | Intercom connection OPEN MESH




Change intercom channel OPEN MESH (1>2>3>4>5>6>7>8>9> Exit>1>2>...)




Mesh Intercom - GROUP MESH

GROUP MESH mode




Bluetooth® Intercom - pairing

Intercom pairing 2 units | Intercom pairing 3 units | Intercom pairing 4 units




Bluetooth® Intercom - conference

Intercom conference | Intercom group conference



Bluetooth® Intercom - other pairings

Other Interphone series pairing (to be done with unit OFF)



Setup

